









Нарезание резьбы метчиком					Расточка		
Нарезание резьбы цельным метчиком	Быстросменные RC	Цанговые патроны TG	Цанговые патроны ER	Цанговые патроны DA	Переходники TA	Переходник Romicron	ModBORE
							
Быстросменные КМ							
		84	84				
		110	111	112			117
184	184	178	179	180			189
246	246	240	241	242			250
	310	305	306				311
	338	330	331			339	
		351	352				
Державки с конусной поверхностью HSK							
		363	364				
		368	369				
	385	378	379			386	
		390	391				
	409	402	403			410	
			415				
			418				
			421				
			424				
			430				
			434				
			437				
V-образный фланец с крутым конусом							
		445	446	447			
472	471	460	461	464	472	474	
			462				
496	496	485	486	489	497	498	
			487				
527	526	516	517	520	524	528	
		515	518-519				
554	553	541-542	543	546	551	556	
		539	544-545				
580	579	570		573		580	
		569	571-572				
599	599	589		593		600	
		588	590-591	592			
Быстросменные Erickson							
		606		607			
		609		610			
		613					
R8							
				618			
Цанговые патроны и втулки							
733	733	656	690	712			

• Цифры на графике означают ссылки на страницы.